
INSTALLATION INSTRUCTION MANUAL

VINYL CASEMENT WINDOW WITH NAIL FIN

(ASPECT™ & ENDURE™)



**** Find QR Codes inside for additional information, helpful installation tips, and videos.***

**** Find QR Code on back for the SPANISH version of this instruction.***
(Para obtener la versión en ESPAÑOL, escanee el código QR ubicado en la última página de estas instrucciones.)

Contact the local recycling waste management center for waste disposal in the area. Always check local waste requirements and carefully dispose of waste in accordance with Federal and other regulations.

Homes built before 1978 may contain lead paint. All replacement installations must comply with the U.S. EPA's Lead-Based Paint Renovation, Repair, and Painting Program (RRP Rule). Read more about the RRP Rule and lead-safe work practices, on the U.S. EPA's website at: www.epa.gov/lead

ProVia®
THE PROFESSIONAL WAY

GETTING STARTED

TOOLS & MATERIALS YOU WILL NEED

- Tape Measure
- Pencil
- Shims
- Drill & Drill Bits
- Utility Knife
- High Quality Silicone Caulking in accordance with ASTM C920, Class 25 & Caulking Gun
- AAMA approved Low-Expanding Window Insulation Foam in accordance with ASTM C1620
- Putty Knife
- Square
- Level
- Hammer or Mallet
- (1) Box Stainless Steel or Galvanized Roofing Nails
- Adhesive Flashing Tape in accordance with ASTM D779
- Weather-Resistant Barrier Paper

REMEMBER: ALWAYS USE THE APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT.

Read these instructions carefully before starting installation. Product warranty does not cover damages resulting from improper installation.

IMPORTANT NOTES BEFORE YOU BEGIN

- Inspect your package(s) for any visible damage to the product. In addition, double check your paperwork with label on product(s) and verify all information is a match. Open packaging to confirm style, color and that order was shipped complete. Double check size of new unit by comparing it for fit to opening.
- If damage or irregularities are found, please scan the product's packaging QR Code label using your phone's QR Code Scanner to access ProVia's After Sale Product Support to enter a request and post pictures/videos to the order, or you can call the Customer Support Team at 1-800-669-4711.
- If you have ordered optional items, verify that they are included in packaging contents. This includes checking for multiple packages (For example, 1 of 2 and 2 of 2).
- For a helpful video on 'Critical Steps: Casement Window Installation', please SCAN or TAP the QR Code.

ASPECT™ & ENDURE™ VINYL CASEMENT CONTENTS

NOTE: Please refer to information below for assembly and installation contents.

Assembly Contents

Vinyl Window Unit (3¼" Main Frame Depth) with Nail Fin

OPTIONS:

- Integral Nail Fin, Extruded into Window Frame
- Applied Nail Fin, Factory Attached with Corners Welded
- Applied Nail Fin, Shipped Loose
- Applied Nail Fin with J-Channel, Factory Attached with Corners Welded
- Applied Nail Fin with J-Channel, Shipped Loose
- Applied Brickmold Nail Fin w/ J-Channel (3 Sides with Sill Brickmold) - Shipped Loose
- Applied Brickmold Nail Fin w/ J-Channel, (All 4 Sides) - Shipped Loose

MULLION KIT: (Only included when field mulling is necessary): *(Refer to separate instruction)*

- Zero Mull Rebar, Part #: S-AE-4710-00
- Zero Snap Mulls, Part #: S-VE-4492-CC
- Header Cover, Part #: S-VR-462-CC (Flat with Nail Fin)
- Stacking Plate Pack, Part #: S-HG-604P-00

Installation Pack

S-HS-515S-CC
(CC = Color Code)

(6) ⅜" Low Profile Hole Plug, (Color Matched), Part #: S-HG-698-CC




(6) #8 x 2" Phillips Pan Head Screws, Part #: S-HS-046-00



Accessory Installation Pack

S-HG-330S-00

(2) Nailing Fin Corner Seal Pads, Part #: S-HG-330-00



(16) #6 - 20 x 3/8" Phillips Pan Head Screws, Part #: S-HS-771-00
(Used for AERIS window units ONLY)



WINDOW INSTALLATION GUIDELINES

- Windows achieve maximum performance from proper installation methods. It is critical to maintain consistent margins between sash and master frame.

- A window gains strength from the surrounding wall structure. This is obtained with proper sizing, support and installation methods.

- Use a high quality grade of silicone with a neutral base.

- Approved sealants for this use must meet the requirements of ASTM C920, Class 25.

- The plastic applied to UV resistant paint finish windows is for the protection of the paint finish and should remain on the window until the installation is complete.

- **DO NOT OBSTRUCT WEEP HOLES** with flashing or sealant. The weep holes located at the bottom sill area of window are necessary to prevent water accumulation. Covering or applying trim to the product will need to allow for proper drainage. Failure to do so will create a risk of water infiltration.

- Windows should be stored in a cool location. **DO NOT** store in direct sunlight or in non-vented hot containers.

- **IMPORTANT!** Allow for expansion and contraction of the window unit when contacting exterior finish material. For installation of the finished exterior material surrounding the window, scan or tap the QR code shown for all gap recommendations per exterior material type.
  THIS INFORMATION MUST BE PASSED TO THE EXTERIOR FINISH INSTALLER.

- Window flashing must be used with all window installations to prevent air and water infiltration. Flash all windows in accordance with the ASTM E2112 standards (method A1, shown in this instruction). Use adhesive flashing in all applications or conform to local code.

- All flashing material must be waterproof in accordance with ASTM D779. Use a roller over the applied tape to ensure full adhesion and no voids.

- All flashing and weather resistant barrier (house wrap/building paper) materials must be installed in a weatherboard fashion. Install and layer starting at the bottom and work upward.

- Fasteners for securing the nail fin of the window must be non-corrosive galvanized roofing nails or pan head screws. Nails should be at least 1¾" in length with the head of the roofing nail wide enough to cover the pre-punched slot of the nailing fin. The roofing nail must be able to penetrate the framing material by at least 1". Pan head screws should be at least 1¾" in length and should NOT deform the nail fin.

- **DO NOT INSTALL** new construction nail fin onto foam.

- **DO NOT INSTALL** roofing nails into nailing fin with an air gun or pneumatic device. Doing so will cause distortion or fracture of the nailing fins. All nailing fins must be secured by hand through the pre-punched nailing holes.

⚠ IMPORTANT INFORMATION!


• ProVia® understands there are various methods and conditions affecting the installation of a replacement window. We feel the most critical steps to follow are securing and shimming as instructed in this document.

FIELD MULLED WINDOW UNITS:

• Refer to the separate document, "Field Instruction For Mulling Vinyl Windows". Units must be mulled together before window unit is set into the opening.

A. INSPECT AND PREPARE VINYL WINDOW UNIT

INSPECT WINDOW AND SCREEN



(Figure A.1)

MULLED UNITS WITH FACTORY INSTALLED HEADER COVER



(Figure A.2)


⚠ ***IMPORTANT! For window units with painted exterior, DO NOT remove the protective plastic cover until after installation is completed.***

For units to be field mulled, refer to the included document, "Field Instruction for Mulling Vinyl Windows". After mulling is complete, resume this instruction to complete Sections B - G.

For factory mulled units with a factory installed header cover, if decision is made to wrap cladding with termination into the unit's top accessory groove and the header cover is removed, it is then the responsibility of the installer to provide the adequate protection required to avoid any leakage issue at mulled joint location(s). Joint(s) MUST BE fully sealed.


1. Inspect new window unit and screen for any material damages. Check all moving parts: locks, all operational hardware, glass, etc. **NOTE:** Moving parts can be repaired AFTER window is installed. Scan the product packaging QR Code label to access ProVia's **After Sale Product Support** to enter a request and post pictures to order, or call the Customer Support Team. *(Figure A.1)*
2. Remove screen. Carefully set aside. Screen will be re-installed after installation. *(Figure A.1)*
3. After inspection, close and lock window unit to engage seals, locks, interlocks, and weatherstripping.
4. For factory mulled units with the header cover factory applied, the top nail fin holes must be drilled or punched out from the interior side (back side) of the nail fin with an approx. 3⁄16" hole through all existing holes and through the head cover. Be sure to elongate each hole to match the nail fin slot, allowing for installation adjustments. *(Figure A.2)*

B. WATER RESISTANT BARRIER



(Figure B.1)

1. If water resistant barrier is covering window rough opening, cut as follows to expose opening.
   a. Cut the water barrier even with the top edge of the rough opening.
   b. Cut the water barrier at an inverted 'Y' in center of rough opening, each leg at a 45° angle to corner, as illustrated. *(Figure B.1)*




(Figure B.2)

2. Fold the water resistant barrier to the inside of each jamb side and sill. Trim each flap to center of jamb. *(Figure B.2)*

3. Apply adhesive flashing tape to the water resistant barrier cut edge at each jamb side to seal edges. *(Figure B.2)*

   NOTE: DO NOT apply tape to the top or bottom cut edge of the water barrier until noted in the instruction.




(Figure B.3)


4. Cut a 45° angle in the water resistant barrier at each top corner. Cut should extend approximately 1" above the head flashing tape (to be installed in later step). *(Figure B.3)*

5. Lift the water resistant barrier flap up and away from rough opening. Apply adhesive tape to hold in place, as illustrated. *(Figure B.3)*


B. WATER RESISTANT BARRIER *(CONTINUED)*



6 Apply adhesive flashing tape to the front face of wall, below sill. Top of tape should align with the sill edge. Extend each end of the flashing tape to width of side flashing (to be installed in a later step). *(Figure B.4)*



7 Apply adhesive flashing tape to the sill. Tape should begin and end approximately 6" above sill on each jamb side. Be sure to wrap tape over the front edge of wall, as illustrated. Wrapping tape will seal and protect wood from moisture leakage. *(Figure B.5)*





8 Place and level shims on the sill, (1) against each jamb side of opening. Shims will provide support to window jambs and level window sill. Be careful shims DO NOT tilt sill toward inside of home. For mulled sets, place shims under all side jamb locations. *(Figure B.6)*


NOTE: If foam wrap is used under sill, shim thickness **MUST** be increased to prevent foam wrap from crowning the sill.

NOTE: DO NOT OVER SHIM below the jamb sides. This will cause unit head to press tightly against opening head, leading to vinyl expansion issues.

C. PREP ACCESSORY AND SET WINDOW UNIT







1. **For window with Integral Nail Fin**, the exterior accessory groove will be exposed. Proceed to **Step 7**.

2. **For an accessory (nail fin with J-channel, or brickmold with J-channel) that is factory applied or shipped loose,** the accessory will occupy the exterior accessory groove. Proceed to **Step 3**.

3. If the vinyl accessory is shipped loose, apply at this time. For specific instructions on all snap-in accessories and for the brickmold with J-channel, refer to "Field Instruction for Window Accessory Installation" QR code on back of this instruction.

4. For mulled units and units with a field installed vinyl accessory, open the non-welded corner miter by pushing outward on joint. Fill the open corner with caulking. Reseat the corner and remove any excess. Repeat on all sides. *(Figure C.1)*

5. Apply corner seal pads (pack #: S-HG-330S-00 - *note, screws from pack will not be used*) or adhesive flashing tape to each exterior corner miter of the vinyl accessory. Be sure to cover miter fin joint in full. *(Figure C.2)*

6. Apply a bead of caulking along interior side of each closed corner miter to seal. *(Figure C.3)*


7. Apply a bead of caulking around entire inner perimeter joint, where accessory meets the frame, for a complete seal. *(Figure C.3)*

NOTE: For mulled units using integral nail fin with J-channel, apply a bead of caulking around entire perimeter joint, where the end of the integral nail fin meets the backside of J-channel, as shown. *(Figure C.3)*

C. PREP ACCESSORY AND SET WINDOW UNIT *(CONT.)*

APPLY CAULKING TO OPENING


Apply a generous bead of caulking to the exterior sheathing to seat and seal nail fin



(Figure C.4)

FASTEN NAIL FIN CORNERS

Use horizontal slots



(Figure C.5)

8 Apply a generous ⅜" bead of continuous caulking to the exterior sheathing to seat and seal nail fin when installed. *(Figure C.4)*

NOTE: Option to apply a ⅜" bead of continuous caulking to the back side of the nail fin to form a complete seal to sheathing.


9 Place window unit into opening and onto sill shims. Center and square unit within opening. Push nail fin against sheathing and water resistant barrier to bed window unit, forming a tight seal between window and water barrier. *Install window unit immediately after the caulking is applied and before a skin forms on caulking's surface.*

NOTE: If top of window is against top of opening, reduce height of bottom shims. Shims are still required below sill as specified.


10 After sill is shimmed, levelled, and preliminarily squared; install a fastener into the horizontal slot at each nail fin corner to secure unit in place. **DO NOT OVER TIGHTEN FASTENER.** This will allow for adjustment in following steps.

NOTE: DO NOT use power tool to install fasteners.


D. INSTALLATION



(Figure D.1)



(Figure D.2)



(Figure D.3)

Frame alignment is critical for the success of the installation and sash operation. Steps 1-3 provide critical frame alignment reference checks to identify and correct if needed through the full installation procedure.

1. Check the plane of the window unit. Each vertical jamb side frame should be equal and parallel to the other. See illustration for equal and unequal plane. *(Figure D.1)*

2. Check to be sure frame jambs do NOT bow inward or outward of the sash, resulting in sash and hardware interference. *Note, window hardware should not be visible between exterior sash weather strip and frame. (Figure D.2)*


3. Check to be sure the vertical face of the window unit is flat, the vertical face can **NOT** bow towards the interior or exterior. A bowed vertical face will cause the frame to be out of alignment, resulting in sash to frame hardware interference. *(Figure D.3)*

IMPORTANT! The frame alignment will need to be CONTINUOUSLY monitored throughout full installation.

D. INSTALLATION *(CONTINUED)*

SECURE - INTERIOR VIEW

Install a screw in each top screw location




Install a screw in bottom HINGE side screw location

(Figure D.4)

INTERIOR VIEW

Adjust jamb screws as needed for square



Install shims directly below operator
Adjust sill shims under jambs for level

(Figure D.5)

4 Unlock sash and carefully open. Install a #8 x 2" Phillips pan head screw into each factory prepped TOP jamb screw location and BOTTOM HINGE side screw location to hold in place. **DO NOT OVER TIGHTEN screws causing frame to pull!** *Be sure to check for proper operation of the sash throughout the full installation process.* *(Figure D.4)*

5 Install shims directly below operator. **DO NOT install screws through sill!** *(Figure D.2)*

NOTE: DO NOT OVER SHIM below side jambs. Over-shimming will press unit head tight against opening head, resulting in vinyl expansion issues.

NOTE: For egress units, operator will not be centered below window.

6 Check for overall square of window unit by measuring diagonally from corner to corner, each side. Adjust top jamb screws as needed. *Recommended tolerance for the diagonal measurement is ⅛". (Figure D.5)*


7 Use sill shims to adjust/re-adjust sill to level as needed. For mulled units, be sure shims are placed directly under mull location for support. *(Figure D.5)*

REMINDER: If foam wrap is used under sill, shim thickness **MUST** be increased to prevent sill from crowning.

D. INSTALLATION *(CONTINUED)*

SECURE - INTERIOR VIEW

Install screws in remaining factory prepped screw locations




***Continuously monitor margins**


(Figure D.6)

SECURE - INTERIOR VIEW

UNITS 28" WIDE OR GREATER, may need secured with (4) screws



MULLED UNIT OR T-MULL UNIT, a screw MUST be installed 3" from each side of mullion on ALL mulled sets



**If mulled set is greater than 56" overall, additional head screws may need added as shown*

(Figure D.7)

⚠ ***IMPORTANT! Shims can be installed prior to installation of screws. It is critical to monitor margins throughout this installation method.***

8 Install bottom screw. Install (2) middle screws until screws are close but NOT seated to the vinyl *(this will allow for side margin adjustment in a later step)*. Inspect all margins. **DO NOT OVER TIGHTEN SCREWS!** *(Figure D.6)*

NOTE: If spacing between jamb screws is greater than 24", additional jamb screws may need added to stabilize frame. Pre-drill a ⅛" thru-hole followed by a ⅜" hole through first wall of frame.

NOTE: Additional jamb screws may need added if foam wrap is used on jambs, causing difficult sash operation.

9 Securing the frame header:
For units 28" wide or greater, the header may need secured to the opening header. Install (4) #8 x 2" Phillips pan head screws. Position in same frame channel as jamb screws. Space equally. *Additional header screws and hole plugs are not provided. (Figure D.7)*


For ALL MULLED UNITS or T-MULL UNITS, a #8 x 2"screw **MUST** be installed into the frame header 3" from each side of the mullion. For a mulled unit with corner drive system, install screw through open hole in the corner drive. *If mulled set is greater than 56" overall, additional head screws may need added as shown. (Figure D.7)*

D. INSTALLATION *(CONTINUED)*

SHIMMING APPLICATION


CORRECT

Flat shims or wedge shims stacked to create a flat plane will result in equal margins




NOT CORRECT

A wedge shim will cause frame to roll resulting in unequal margins



(Figure D.8)

SHIMMING - INTERIOR VIEW




Place stacked shims next to factory prepped screw locations

DO NOT place shims at top header and bottom sill locations

(Figure D.9)

SECURE NAIL FIN




Install fasteners in every other pre-punched hole

(Figure D.10)

IMPORTANT! ***Shims are needed to achieve required margins. All margins need to be CONTINUOUSLY monitored throughout installation. Shimming as instructed in Step 10 is critical to maintain stability of the frame.***

IMPORTANT! ***CORRECT*** *shimming application; stack wedge shaped shims contrasting and plane to plane. See diagram below.* ***DO NOT*** *use a single wedge shim. This will cause the frame to roll, resulting in unequal margins. (Figure D.8)*



10 Place shims next to all screw locations. **DO NOT PLACE SHIMS WITHIN 4" OF TOP OR BOTTOM CORNERS.** This will cause frame distortion. If spacing between side jamb shims is greater than 12", additional shims may be needed to maintain margins and stabilize frame. **CONTINUOUSLY CHECK SASH TO FRAME MARGINS WHILE SHIMMING.** *Note, window hardware should not be visible between exterior sash weather strip and frame. (Figure D.9)*

11 Final check on frame alignment. Adjust shims and screws as needed to achieve and maintain equal and straight alignment, all sides. ***Refer back to Figures D.1, D.2 and D.3.***

12 **Check for proper operation of sash.** For sash operation issues, refer to Troubleshooting Section.


13 Fully secure each center/middle screw. **DO NOT OVER TIGHTEN.**

14 Install fasteners in pre-punched nail fin holes, all sides. Install fasteners in every other hole or as needed to keep nail fin flat. **DO NOT OVER TIGHTEN.** *(Figure D.10)*

E. FLASHING

EXTERIOR JAMB SIDE FLASHING TAPE

Begin jamb side tape ½" below where top edge of header tape will be, stop ½" above bottom sill tape edge




(Figure E.1)

1. Apply adhesive flashing tape to each jamb side. Begin top of the side flashing approximately ½" below where the top edge of header flashing will be placed (Refer to Step 3). Stop the bottom of the side flashing approximately ½" above bottom edge of front face sill flashing. *(Figure E.1)*

NOTE: If window unit has snap-in nail fin, wrap tape onto the window frame, approximately ¼".

EXTERIOR FLASHING TAPE

Apply flashing tape to header - top of head flashing to be ½" above top of side flashing



(Figure E.2)

2. Apply adhesive flashing tape to the header. Place top of the head flashing approximately ½" above top of the side flashing. Extend each end of the head flashing approximately 1" beyond side flashing. *(Figure E.2)*


NOTE: If window unit has snap-in nail fin, wrap tape onto the window frame, approximately ¼".

EXTERIOR FLASHING TAPE

Remove tape holding water resistant barrier flap

Lower flap over head flashing

Trim flap if needed




(Figure E.3)

3. Remove tape holding the water resistant barrier flap above header. Lower flap over header flashing. Trim to top of window frame if needed. *(Figure E.3)*

E. FLASHING *(CONTINUED)*

EXTERIOR FLASHING TAPE

Apply flashing tape to bottom edge of water barrier
Tape each 45° corner




(Figure E.4)

4. Apply adhesive flashing tape to bottom edge of the water resistant barrier flap. *(Figure E.4)*

5. Apply adhesive flashing tape to each 45° corner of the water resistant barrier for a complete seal. *(Figure E.4)*

F. INSULATE

LOW-EXPANDING FOAM - MARGIN CHECK



(Figure F.1)

1. Install hole plugs into all jamb screw locations.

2. Close and lock sash.


⚠ ***IMPORTANT!*** ***Sash must operate properly before and after application of foam insulation.***

3. Insulate by using an AAMA approved ASTM C1620 low-expanding foam to fill all cavities between frame and opening. Check and maintain all margins during insulating. ***Over use of low-expanding foam may cause frame to bow, jeopardizing operation of window. (Figure F.1)***

4. If **MasterFit™ Trim** is ordered, **DO NOT** nail trim to jamb extension. Refer to QR code on back for measuring assistance.

G. SASH TO FRAME ADJUSTMENTS

BOTTOM OF SASH/FRAME VIEW




(Figure G.1)

1. For SASH ADJUSTMENT, unlock and open sash. Use a flat head screwdriver to remove arm from each cam nut located on top and bottom hinge track. Use a crescent wrench to slightly rotate each cam nut 1/16" to the exterior or 1/32" to the interior. *(Figure G.1)*

NOTE: The ProVia HG05 hinge wrench can be ordered from our Customer Support Team for adjustment of the cam nut without removal of the arm. (Request part # S-HG-0111-00)

BOTTOM OF SASH/FRAME VIEW




(Figure G.2)

2. For SASH REMOVAL, unlock and open sash. Use a flat head screwdriver to open the clip located below the attached LONG arm, near the strike side. Use a flat head screwdriver to open the clip located below the SHORT arm, attached to the sash near the hinge side. Move each arm away from sash. Lift below cam arm to remove arm from cam nut, both top and bottom. Move each cam arm away from sill. Hold sash secure, slide the top and bottom sash shoes towards the open side of hinge track. Remove sash from frame. Reverse order for re-installation. *(Figure G.2 & G.3)*

NOTE: Smaller casement windows will use a single arm operator.

NOTE: Refer to the QR codes at the end of this document for a more detailed, complete instruction of sash removal 'Casement Sash Removal with ROTO Hardware' and a helpful video 'Removal and Installation of a Casement Window Sash'.

TOP & BOTTOM OF SASH/FRAME VIEW



(Figure G.3)

TROUBLESHOOTING & TIPS

PROBLEM	CAUSE	SOLUTION
Top of sash leans outward while closing	Normal/typical.	This is a normal occurrence as long as the top of the sash pulls in tight when closed. If sash does not pull tight, adjust keepers to engage tie rod post in succession, to achieve a zipper like effect from bottom to top. Lift block may be missing. Refer to the "Keeper and Tie Rod Adjustment" QR Code at the end of this instruction for more detail.
Lock lever becomes hard to operate halfway down	The keepers are not properly aligned with the tie rod post. Multiple keepers are engaging the tie rod post at the same time.	Adjust keepers to engage tie rod post in succession, to achieve a zipper like effect from bottom to top. Lift block may be missing.
Sill bows upward	1. No shims below jambs. Critical on mulled units. 2. Over insulating or over shimming below sill. 3. Insufficiently shimming under jambs when foam wrap is used under sill. 4. Installing fasteners in nail fin units prior to proper setting and alignment of window. 5. Supporting nail fin unit on bottom center fin hole. 6. Exterior trim is tight against window, not allowing for vinyl expansion in the heat. 7. Jamb side shims placed too close to bottom sill locations, not allowing for vinyl expansion in heat.	1. Add shims to window sill per this instruction. 2. Remove foam. Re-square and level window unit. Refer to this instruction for proper insulation procedure. 3. Re-shim window unit per this instruction. 4. Remove fasteners except at each corner. Square and level unit per this instruction. Set proper margins per this instruction before re-installation of nail fin fasteners. 5. Remove fastener from center fin. Install a fastener at each corner of nail fin to secure window unit in place. 6. Refer to "Installing Exterior Veneers to Windows" QR code at end of this instruction. 7. Remove shims at bottom jamb side sill locations. Shim per this instruction.
Header bows downward	1. Excessive foam or over insulating above header. 2. Installing fasteners in nail fin units prior to proper setting and alignment of window. 3. Excessive foam or insulation on nail fin units prior to fastening nail fin. 4. Jamb side shims placed too close to top header location, not allowing for vinyl expansion in heat.	1. Remove foam above header. Re-foam per this instruction. 2. Remove fasteners except at each corner. Square and level unit per this instruction. Set proper margins per this instruction before re-installation of nail fin fasteners. 3. Remove foam. Re-foam per this instruction. 4. Remove shims at top jamb side header. Shim per this instruction.
Frame racked or out of square	Improper or no shims below the jambs.	Re-shim window unit per this instruction.
Tall unit side jamb margins are not consistent in width	Under shimmed and under secured.	Add additional jamb screws. Place shims at additional jamb screw locations.
Sash alignment is restricted	Outside corners of sash have an excess weld build-up.	Remove the excess weld on corners and from both sides of the bulb seal until a square corner is achieved.
Sash is leaning downward and unable to pull in at the bottom	Lift block is missing.	Locate lift block next to sill slide track, with bevelled edge facing the exterior side.

TROUBLESHOOTING & TIPS

PROBLEM	CAUSE	SOLUTION
Window leaks water at accessory corners	1. Improper or no caulking on backside corners of accessory. 2. Improper or no caulking at accessory to frame joint.	1. Caulk accessory per this instruction. 2. Caulk accessory per this instruction.
Water leaks on multi-level mulled units	Missing or improper caulking behind exterior mull strip at T-joint or cross joint.	Caulk zero snap mulls. Refer to the "Field Instruction for Mulling Vinyl Windows" QR code below.
Condensation is present on inside or outside glass of window	Various normal conditions/reasons.	Refer to "Condensation, Humidity and Dew Point Temperature" QR code below for a detailed explanation of normal condensation conditions.
Hardware is visible between exterior sash and frame	Frame is rolled due to lack of proper shimming.	Re-set side jambs per Section D.

Please call Customer Support for additional installation inquiries at 1-800-669-4711.

For additional information and helpful videos, SCAN or TAP the QR Codes.

VISIT OUR INSTALLATION SUPPORT HOMEPAGE

Field Instruction Mulling Vinyl Windows (Aspect & Endure)

Field Instruction for Window Accessory Installation

Install. Instruction Vinyl Window Stacking Plate #604

Measuring Instruction MasterFit™ Trim

Installing Exterior Veneers to Windows

Condensation, Humidity and Dew Point Temperature

Casement Sash Removal with ROTO Hardware

Video: Removal and Installation of a Casement Window Sash

Video: How to Adjust ProVia Casement Window Sash

Version 1.8 · 10.12.2026 · © 2026 ProVia · S-MK-03073

ProVia® THE PROFESSIONAL WAY

2150 State Route 39, Sugarcreek, OH 44681
Phone: 330.852.4711 • Fax: 877.735.2057
provia.com