


SIDELIGHT PANEL REMOVAL AND REINSTALLATION INSTRUCTIONS

INSWING UNIT

A. UNPACK NEW SIDELIGHT SLAB, CONFIRM THAT SIZE, COLOR, ARE CORRECT

B. REMOVAL OF EXISTING SIDELIGHT

1. REMOVE INSIDE VERTICAL CASING AROUND PERIMETER OF UNIT.
2. FIND LOCATION OF SCREWS AROUND PERIMETER OF SIDELIGHT



SCREW LOCATION DIAGRAM

KEY:

- Ⓐ 5 SCREWS FROM OUTSIDE OF JAMB INTO EACH OF THE SIDELIGHTS
- Ⓒ 1 SCREW BEHIND EACH HINGE ON A HINGE SIDE SIDELIGHT
- Ⓓ 1 SCREW BEHIND DEADBOLT STRIKE PLATE
- Ⓔ 2 SCREWS LOCATED ON STRIKE SIDE JAMB APPROXIMATELY 8" FROM HEADER AND THRESHOLD. SCREWS ARE RECESSED AND HOLE IS FILLED WITH LIGHT SPACKLING AND PAINTED.

3. LOCATE OUTSIDE Ⓐ AND TOP Ⓓ JAMB SCREWS BY INSERTING A LIGHT DUTY PUTTY KNIFE BETWEEN SIDELIGHT SLAB AND JAMB SLIDE PUTTY KNIFE BACK AND FORTH, OR UP AND DOWN TILL A SCREW IS DETECTED
4. CUT SCREWS WITH A SHARP HEAVY DUTY PUTTY KNIFE AND RUBBER Mallet OR DEAD BLOW HAMMER.

5. FOR STRIKE SIDE SIDELIGHTS, REMOVE LOCKSET AND DEADBOLT STRIKE PLATES. REMOVE Ⓓ SCREW BEHIND DEADBOLT STRIKE PLATE AND THE 2 Ⓔ SCREWS THROUGH JAMB TOP AND BOTTOM.
6. FOR HINGE SIDE SIDELIGHTS, REMOVE HINGES AND DOOR SLAB FROM JAMB. REMOVE THE 3 Ⓒ SCREWS, 1 BEHIND EACH HINGE.


7. SIDELIGHT CAN NOW BE REMOVED BY PUSHING SLAB TOWARD INSIDE OF HOUSE. AFTER SLAB CLEARS THE TOP OF THE JAMB ON THE INSIDE OF THE HOUSE, IT CAN THEN BE PICKED UP OUT OF THE THRESHOLD CHANNEL AND REMOVED FROM THE JAMB

C. RE-INSTALLATION

1. CHECK ALL GASKETS AND JAMB FOR CLEANLINESS AND PROPER PLACEMENT
2. PRE-DRILL HOLES FOR SCREWS ALONG OUTSIDE JAMB AT 45° ANGLES
3. INSTALL BOTTOM BLACK SILL SUPPORT INTO THRESHOLD AND REMOVE FACE COVER FROM DOUBLE FACE TAPE
4. INSERT NEW SIDELIGHT SLAB INTO JAMB, MAKE SURE INSIDE OF SLAB IS TOWARDS THE INSIDE OF HOUSE
5. INSTALL DRYWALL SCREWS AROUND PERIMETER OF SIDELIGHT, USE 1-5/8" SCREWS ON THE OUTSIDE AND TOP, AND 2" SCREWS ON STRIKE SIDE AND HINGE SIDE.
6. FILL HOLES ON STRIKE SIDE WITH LIGHT SPACKLING, LET DRY. SAND LIGHTLY AND TOUCH UP WITH MATCHING PAINT.
7. REINSTALL DOOR SLAB AND STRIKE PLATES
8. REATTACH INTERIOR CASING
9. RESEAL BOTTOM AREA OF SIDELIGHT EXTERIOR, WHERE THE BLACK SILL SUPPORT AND SIDELIGHT MEET WITH A CLEAR ALL-WEATHER CAULK
10. MAKE SURE THAT ORIGINAL CUT SCREWS ARE NOT PROTRUDING INTO THE OPENING

D. TIPS AND TROUBLE SHOOTING

1. ON SIDELIGHT UNITS WITH BUILD UP BETWEEN DOOR AND SIDELIGHT THE SCREW PLACEMENT IS DIFFERENT. REMOVE INSIDE MULL TRIM. SCREWS ARE INSTALLED AT AN ANGLE THROUGH BUILD-UP. REMOVAL AND INSTALLATION CAN BE DONE EASILY.
2. OUT SWING UNITS, OUT SWINGS HAVE A SIMILAR SCREW PATTERN, EXCEPT THEY ARE LOCATED FROM THE OUTSIDE AND BRICK MOLD NEEDS TO BE REMOVED INSTEAD OF INTERIOR CASING.



CAUTION: DO NOT DRILL THROUGH FACE OF SIDELIGHT

